



Bulletin 54000

A Positive Safeguard — Indicates lubricant flow or no flow

DESCRIPTION


The Manzel Lube-Line Alert is an easily installed device proriding positive protection for compressors, pumps, engines and equipment employing any make or type of force feed ubrication system. Installed as close to each point of lubrication as possible, the unit acts as a sentinel to indicate flow or no-flow at any point in the system ahead of the Lube-Line Mert inlet.

One Lube-Line Alert per Pumping Unit will warn of flow stoppage for any reason including low reservoir lubricant evel; shaft rotation stoppage; broken lubricant lines; dirt under pump valves and worn plungers.

\ single Lube-Line Alert per Lubricator will warn of low eservoir lubricant level or shaft rotation stoppage.

For complete protection, there should be as many Lube-Line Mert units in your installations as there are points of lubrication.

The Manzel Lube-Line Alert provides low-cost, dependable protection for costly machinery



Typical wiring diagram for fail safe operation using Lube-Line Alerts assembled in N.O. normally open position. Alerts installed in a 110V control circuit side of motor starter to provide positive system protection through automatic system shut down.

FEATURES

ndicates Flow or No-Flow at any point in the system ahead of the Lube-Line Alert inlet. Not affected by discharge pressure.

Operates under continuous or intermittent low-flow ates.

Jniversal use — operates in any air free force feed lubrication system — any make lubricator.



Sensitive to a wide range of flow — from .006 cubic inches to 190 cubic inches per minute.

Many type lubricants and viscosities — mineral or synthetic.

Time delay adjustment — to compensate for viscosity and/or flow rate. Quick and easy to adjust.

Pressures — for operation up to 10,000 psi.


Explosion-proof — UL and CSA Listed for Class I Groups C & D and Class II Groups E, F & G, Division 1 & 2 when installed as per National Electrical Code.

For connection to any electrical warning system — lights, sound devices, machinery shutoff relays, telephones, etc.

A low-level and shaft rotation indicator — equip one pumping unit per reservoir with Lube-Line Alert.

SPECIFICATIONS

Electrical	Single pole, single throw magnetically operated switch
	, 60Hz, 10 Watt, 1 Amp load . 28 VDC, .5 Amps resistive,
	.5 Amps inductive (L/R .026)
Operating Pressure	10,000 psi (Max.)
Pressure Drop Across Alert	150 psi (Min.)
Flow Range0	06 cu. in. to 190, cu. in. per
n	ninute at 100 SUS at 100° F.
	006 cu. in. to 75.0 cu. in. per
mid	nute at 2,000 SUS at 100º F.
Fluid Viscosity	min., 100 SUS at 100º F.,
1	max., 2,000 SUS at 100º F.*
Weight	1.6 pounds



OPERATION

The Manzel Lube-Line Alert is composed of a separate hydraulic body and a switch body botted together. The hydraulic body consists of a plunger, a magnet, a spring, and an adjustable plug. The switch body consists of a hermetically sealed magnetically-actuated switch set in a potting compound. The switch body can be mounted in one of two alternate positions: and for (N.O.) approximate positions: and for (N.O.) approximate positions: alternate positions: one for (N.O.) normally open contacts (during no flow), the other for (N.C.) normally closed contacts (during no flow) to accommodate various alarm or shut down circuits.

Lubricant flowing through the Alert moves the plunger and magnet until the plunger has opened the cross port in the bushing. This movement of the magnet opens the contacts for the (N.C.) normally closed switch position and closes the contacts on the (N.O.) normally open switch position, thus breaking or making the electrical circuit. The lubricant then moves through the cross port, around the magnet, through the hole in the plug and on to the point of lubrication. This path is shown in grey.

When flow stops, the spring returns the magnet and plunger toward their original position. When this movement is sufficient, the magnet closes the contacts for the (N.C.) normally closed switch position or opens the contacts for the (N.C.) normally open switch position, making or breaking the alarm or shut down circuit.

There is a built-in external time delay to adjust for various flow rates and/or viscosities, which can be easily varied by sliding the switch body "O" mark in relation to the N.C. or N.O. mark on the hydraulic body. With the N.C. or N.O. mark opposite the "O" mark, the longest time delay - from flow stoppage to indication - will be obtained. An internal screw adjustment provides an additional time delay adjustment range. This can be varied by removing the Alert outlet connection and turning the slotted screw clockwise, to decrease the delay time and counter clockwise, to increase the delay time. These adjustments should be made in 1/4 turn increments and with the N.C. or N.O. mark opposite the "O" mark.

A light spring is included (loose) with the Lube Line Alert (P/N 456-060-009 only). This spring is to be used in low flow applications where the unit fails to actuate.


INSTALLATION

Cut the line as close to the point of lubrication as practical. Install the Alert with proper flow direction as shown on the nameplate. Straight or elbow fittings are available in most tubing or pipe thread sizes for the 7/16-20 NP straight thread "O" ring Alert ports.

The electrical swtich housing should be set at the proper switch position - N.O. opposite "O" for normally open circuitry (during no flow) or N.C. opposite "O" for normally closed circuitry (during no flow). Lead wires from the switch are ready for connection through the 1/2" conduit connections to a suitable alarm circuit.



WARNING—Visual and/or Audio and/or Mechanical



Fail safe circuitry can only be provided by using the N.O. (normally open) switch position. Multiple Alerts must be wired in series or through senarate circuits.

For the N.C. (normally closed) switch position multiple Alerts should be wired in parallel or through separate circuits.

The loose cover must be assembled over the exposed machined face of the Alert hydraulic body to meet Underwriters' Laboratory listing. To reduce the risk of ignition of hazardous atmospheres, conduit runs must have a sealing fitting connected within 18 inches of the enclosure.

Installation at point of lubrication provides complete protection, including detection of broken lines up stream of Alert.

ORDERING INFORMATION

Order Part Number

463-001-211

Lube Line Alert

N.C. configuration with check valves for 1/4" O.D. tube. standard spring (installed), with light spring (loose)*. 456-060-009 N.O. configuration with check valves for 1/4" O.D. tube, light spring (installed), with standard spring (loose)*. 456-060-181 N.O. configuration with check valves and fittings for 1/8" NPTF connections, standard spring (installed)... 456-060-109

Accessory Parts

Inlet Check	k Valves				
With 1/4"	Q.D. tube i	nlet (su	pplied w	ith 456-0	60-009
and 456-	060-181)				
IAKIN THE	On atraight	famala	throad is	det /eur	فنبد لمحتلم

With 7/16-20 straight female thread inlet (supplied with **Outlet Check Valves**

With 1/4" O.D. tube outlet (supplied with 456-060-009) and 456-060-181)..... With 7/16-20 straight female thread outlet (supplied with

Fittings (use with check valves 463-001-201 and 463-001-221) 7/16-20 straight male thread X 1/8" NPTF (2 supplied

Springs

Standard Spring (installed at factory in 456-060-009 and 456-060-109)..... 458-005-440 Light Spring for low flow applications (supplied loose with 456-060-009, installed in 456-060-181)*...... 458-005-220

Repair Parts

Plunger & Bushing Assembly 456-060-029

* When using the light spring (458-005-220) fluid viscosity should. not exceed 350 SUS.

® Registered trademarks of LUBRIQUIP, INC., A Unit of IDEX Corporation. Printed in U.S.A.